Pyramid TimeTrax sync

NTP INSTALLATION . . . SIMPLE AS 1-2-3

STEP 1

INSTALL THE SUPPLIED PYRAMID TIMETRAX SYNC SOFTWARE ON A LOCAL WINDOWS BASED COMPUTER. SET THE SOFTWARE PREFERENCES USING THE SIMPLE TO USE HELP GUIDE.

STEP 2

LOCATE A CENTRAL SPOT IN THE FACILITY WHERE THE TRANSMITTER WILL BE. SCREW THE SUPPLIED ANTENNA ONTO THE TOP OF THE TRANSMITTER. POWER THE TRANSMITTER BY CONNECTING ONE END OF THE AC POWER SUPPLY TO A WALL OUTLET AND THE OPPOSITE END TO THE BACKSIDE OF THE TRANSMITTER. THEN CONNECT THE SUPPLIED RJ45 CABLE TO AN ETHERNET NETWORK PORT OR PC NIC CARD AND TO THE BACK OF THE TRANSMITTER.

STEP 3

INSTALL THE LITHIUM BATTERY IN THE BACK OF THE CLOCK. LOCATE A GOOD SPOT FOR THE CLOCK THAT CAN BE VIEWED FROM ALL ANGLES. HANG THE CLOCK ON THE WALL.

FOR MORE INFORMATION VISIT:
WWW.PYRAMIDWIRELESS.COM

42408